

ONE WORLD

SYDNEY | CHRISTCHURCH | CHICAGO

# SLIP COVER

---

ASSEMBLY GUIDE



## FOR YOUR SAFETY


---




Protects your floor and product. Lift, don't drag.



Read through the assembly guide before you begin adding the cover.



Assembly requires 1 person. It's always more fun with two!




Assembling this product on clean, soft surface to protect your new sofa and floor.

## COMPONENTS

Before you get started, check you have all of the pieces below. If anything's missing, we'll sort it out right away.


1

Sofa or Armchair  
Frame/base & Cushions



2

Sofa Cover Pack



# SLIP COVER ASSEMBLY

## STEP 1

1. Unwrap and remove the cushions from the sofa frame/base.

## STEP 2

2. Separate the frame/base sofa cover from the cushion covers

## STEP 3

3. Unfold the large base cover and lay it loosely over the sofa frame. Match the 4 corners of the sofa back and arms to the corners of the frame/base cover.



**STEP 4**

4..Pull the cover down on the first back corner, then repeat the opposite corner. Now pull the cover down on the front arm and then do the same on the opposite arm.



**STEP 5**

5. Check seems align to the top of the arms and the back. If not, straighten the frame/base until it is straight.



**CHECK THE SEAMS ARE  
STRAIGHT ON THE  
BACK AND ARMS**

## STEP 6

6. Attach the velcro starting with one arm and work around the sofa smoothing the velcro down until you are back where you started.



NOTE: REPEAT STEP 6 IF THE COVER IS NOT STRAIGHT OR THE FABRIC NOT SMOOTH

## STEP 7

7. Once the main cover is on and aligned, add the covers to the seat cushions.

## STEP 8

8. Starting with one corner of the cushion first, stretch the cover over the cushion. Bend the cushion slightly to allow an easier fit of the cover.

## STEP 9

10. Do the same for the back cushions and the scatter cushions.

**NOW SIT BACK, RELAX & ENJOY!**